



SAIC DESIGN

MG4 ELECTRIC

Service Circuit Diagram

V2.1

SAIC

Foreword

Change History

No.	Action	Type	EWO	Chapter	Version/Date
1	First Version	/	/	/	V2.0 2022/05/31
2	Add X4 X6 X8	Engineering change	EAGDIG	S43-Rear Wiper System	V2.1 2023/03/13

About This Document

General

This document is intended to assist in diagnosing electrical faults. The document is divided into the following sections:

INTRODUCTION - Includes the following contents: ABOUT THIS DOCUMENT, ELECTRICAL PRECAUTIONS, ABBREVIATIONS, WIRE COLOUR CODES, HARNESS ABBREVIATIONS, WIRE OPTION CODES, POWER SUPPLY MODES, CONNECTOR DETAILS, FAULT DIAGNOSIS, HOW TO USE THIS CIRCUIT.

FUSE BOX DETAILS - The information and function of fuses and relays in the engine compartment fuse box and passenger compartment fuse box.

POWER DISTRIBUTION - Provides engine bay compartment and passenger compartment power distribution, it is intended to understand the condition of power distribution.

EARTH LEAD CIRCUIT DIAGRAM - Provide all the ground circuit and put them together, in order to look for earth information quickly for reader.

SUB-SYSTEM CIRCUIT DIAGRAM - Provide each system service circuit diagram.

LOCATION OF CONNECTORES AND EARTH LEADS - Shows the location of connectors and earth leads on the vehicle. For convenience, there will be several connectors or earth leads in one picture.

CONNECTOR DETAILS - Provide the connector faceview, name, description, colour and cavity information.

Battery Voltage

Open Circuit Voltage Test

Before commencing diagnosis of electrical problems, verify the condition of the battery is acceptable by using the open circuit voltage test.

1. Switch off all electrical loads on the vehicle.
2. Adjust digital multimeter to read DC volts on the appropriate scale.
3. Connect test probes across battery terminals ensuring that polarity is correct and record the voltage displayed.

A reading of 12.3V or more is acceptable, any battery which reads less than this will need charging.

Caution: If the vehicle has been used in the last eight hours before testing, the static on the surface of the battery must be removed by turning on the headlight for about 30 seconds. Wait for 60 seconds before checking the open circuit voltage.

Battery voltage is used as a known reference for ascertaining whether or not circuits are receiving sufficiently high voltage for components to function correctly. This reference is only a guide since most electronic circuits are designed to function over a wide range of voltages. In addition, consideration must be given to readings affected by voltage drop across certain components and fluctuations due to cable lengths.

Electrical Protection

General

The following guidelines are intended to ensure the safety of the operator whilst preventing damage to the electrical and electronic components fitted to the vehicle.

Equipment

Prior to commencing any test procedure on the vehicle, ensure that the relevant test equipment is working correctly and any harness or connections are in good condition. This particularly applies to mains lead or connections.

Caution: Before starting any work on power system, make sure the high voltage terminal, adapters and diagnostic equipment for testing have been insulated or shielded absolutely to prevent accidental personal accident and to minimize the risk of shock. The medicinal pacemaker carrier should be away from the power system circuit and the diagnostic equipment.

Polarity

Never reverse connect the vehicle battery and always observe the correct polarity when connecting test equipment.

High-Voltage Circuit

Whenever disconnecting live ht circuits, always use insulated pliers and never allow the open end of the ht lead to come into contact with other components, particularly ECU's. Since high voltage spikes can occur on the terminals of the high voltage components while the vehicle is running, exercise caution when measuring the voltage at these points.

Connector and Wire Harness

The front compartment of a vehicle is a particularly hostile environment for electrical components and connectors. Always ensure these items are dry and oil free before disconnecting and connecting test equipment. Never force connectors apart either by using tools or by pulling on the wiring harness. Always ensure locking tabs are disengaged before removal and note orientation to enable correct reconnection.

Ensure that any protective covers and substances are replaced if disturbed.

Before removing a faulty component, refer to the Workshop Manual repair procedures.

Ensure the START/STOP Switch is turned to the 'OFF' position, the battery is disconnected (see Battery Disconnecting) and any disconnected harnesses are supported to avoid any undue strain at the terminals. When replacing the component keep oily hands away from electrical connection areas and push connectors home until any locking tabs fully engage.

Battery Disconnecting

Before disconnecting the battery, switch off all electrical equipments.

Caution: To prevent damage to electrical components, ALWAYS disconnect the battery when working on the vehicle electrical systems. The earth lead must be disconnected first and reconnected last. Always ensure that battery leads are routed correctly and are not close to any potential chafing points.

High Voltage Precaution Requirements

Precautions related to high voltage systems and electric vehicles:

Unqualified personnel **MUST NOT** come into contact with EV or PHEV vehicles during repair - the correct barriers should be installed to prevent vehicle access.

DO NOT touch or contact any component identified as 'high voltage'

ONLY fully trained personnel should work with high voltage systems.

ALWAYS ensure that the correct insulated personal protective equipment (PPE) is used.

Prior to opening any high voltage circuits the systems **MUST** be checked using a suitable multi meter to ensure they carry no high voltage current.

Where there is need to work with the high voltage system it is essential that the correct 'make safe' procedure is followed - see Manual Service Disconnect procedure in the Service Repair manual.

After disconnecting the Master Safety Device (MSD), always wait 5 minutes prior to commencing any checks for residual voltage etc.

When any work is being carried out on the high voltage system the 12V battery **MUST** remain disconnected.

After disconnection of any HV connector it is essential that the connector and terminals are examined for condition, integrity and security prior to re-connection.

ALL high voltage components **MUST** have a good ground.

Warning: Only personnel that have full EV qualifications recommended by SAIC/MG Motor should undertake work on high voltage components and systems.

Warning: Non qualified staff are NOT permitted to dismantle high voltage systems or components (including, ESS, EDS, HV harnesses, EACP, Charging sockets etc).

Warning: Any qualified personnel working on high voltage systems or components MUST wear the correct insulated personal protective equipment (PPE). All PPE must be regularly checked and tested for condition and integrity.

Caution: When removing or servicing any parts of the high voltage system it is essential that no liquids enter, contaminate or are spilled on components, harnesses or connectors.

Foreword

Abbreviation-1

A	Ampere
A/C	Air Conditioning
ABS	Anti-Lock Braking System
ANT	Antenna
ATC	Automatic Temperature Controller
BCM	Body Control Module
BUS	BUS System
CAN	Controller Area Network
CDL	Center Door Lock
CHSML	Center High Stop Mounted Lamp
CFB	Passenger Compartment Fusebox
DI	Direction Indicator Lamp
DRL	Daytime Running Lamp
EACP	Electric Air Conditioning Compressor
EBS	Electrical Battery Sensor
ECU	Electronic Control Unit
EDU	Electrical Drive Unit
EF	Front Compartment Fusebox Fuse
EPB	Electrical Parking Brake
EPS	Electric Power Steering
ESCL	Electronic Steering Column Lock
ESS	Energy Storage System
EVAP	Evaporator
EVP	Electronic Vacuum Pump
F	Fuse
FL	Front Left
FICM	Front Infotainment Control Module
FR	Front Right
GND	Ground
HRW	Rear Windscreen Heating
HS	High Speed
HVIL	High Voltage Interlock Loop

Foreword

Abbreviation-2

IGN	Ignition
ILLU	Illumination
IMMO	Immobilization
IFP	Information Faceplate
IPK	Instrument Pack
LH	Left Hand
MIC	Microphone
MLS	Master Light Switch
NAV	Navigation
PACM	Pedestrian Alert Control Module
PDC	Parking Distance Control Module
PDU	Power Distribution Unit
PEB	Power Electronic Box
PEPS	Passive Entry Passive Start
PTC	PTC
PWM	Pulse Width Modulated
PWR	Power
RH	Right Hand
RL	Rear Left
RLS	Rain Light Sensor
RR	Rear Right
RVC	Rear Vision Camera
SCRN	Shield
SCS	Stability Control System
SCU	Shift Control Unit
SIG	Signal
SPK	Speaker
SW	Switch
T-BOX	TBOX
TEMP	Temperature
TM	Traction Motor
VCU	Vehicle Control Unit

Wire Colour Code

Code	Description
R	Red
B	Black
O	Orange
S	Slate
K	Pink
N	Brown
Y	Yellow
U	Blue
P	Purple
W	White
G	Green
T	Tan
DG	Dark Green
DU	Dark Blue
LG	Light Green
LU	Light Blue

Caution: Some wires have double colours, such as "YW" means the main colour is yellow and the second colour is white.

Option Code-1

Code	Description
2022	Model Year 2022
3G02	National Code: EU
C21K	Lithium iron phosphate battery 51kWh
C21C	Ternary Polymer Lithium Battery 64kWh
C23A	High Voltage Battery Pack Heater
C23X	NO High Voltage Battery Pack Heater
E05A	Four-Wheel Drive
E05B	Rear-Engine Rear-Drive
F00E	Electric Power Steering
F12H	Steering Wheel Heating
F15E	Electronic Steering Column Lock
H10K	Stability Control System
H10W	ESP SPORT
H11A	AUTO HOLD
H15B	Electronic auxiliary braking
H20A	Adaptive Cruise Control
H30E	Electric parking brake
J17A	Tyre Pressure Monitoring System-Direct
J17P	Tyre Pressure Monitoring System-Indirect
K14B	External air intake grille active closing system
K20B	Power Adjust & Fold Mirror with Heating
K203	Electric Adjust & Manual Fold Mirror with Heating
K61B	Boneless wiper
M10D	Manual Anti-glare Interior Mirror
M35E	Center console power socket
M54A	Luggage compartment lighting
N002	Manual Adjust Driver Seat
N00A	Electric Adjust Driver Seat
N02B	6-way adjustment
N06A	4-way adjustment
N101	Manual Adjust Front Passenger Seat

Foreword

Option Code-2

Code	Description
N201	Independent rear first row seats
N451	Front seat heating, type 1 (3rd gear)
N45W	Front Seat Heating
N45X	No seat heating
Q00S	Dual Airbag & Side Curtain
Q01B	Front Seat Airbag
Q09A	Passenger Airbag Disable Switch
Q15C	Child safety door lock
Q17B	Front seat belt height fixing
Q19R	Driver Seatbelt with Reminder
Q20S	Front & Rear Seatbelt with Reminder
Q26C	Upper and lower fixing points
Q31A	Passenger side airbag, single stage
Q40A	Driver's seat belt pretensioner, type 1
Q41A	Front passenger side safety belt pretensioner, type 1
R40G	Driver information display, color 7 inches
S00A	Headlight, led type A
S00B	Headlight, led type B
S02F	Front fog lamp
S03F	Rear fog lamp
S04A	Light with glove box
S0D1	Intelligent headlamp control system
S10A	Automatic lighting control system
S11D	Daytime running lights
S12L	LED high mounted brake lamp
S14L	Led brake light
S16D	Driver's side glass anti pinch only
S16E	Front door glass anti pinch
S16F	Front and rear door glass anti pinch
S1AB	Through type rear position lamp
S20H	Windshield heating

Foreword

Option Code-3

Code	Description
S27A	With side impact function
S30S	Dual keyless entry
S31F	Senseless start
S32M	Engine anti-theft
S34B	Burglar alarm
S36A	Double snail horn
S37B	Bluetooth Handsfree phone
S40F	Front and rear reversing radar
S40P	Rear drive
S41B	Emergency lane keeping assist system
S41K	Lane keeping assist system
S43A	With automatic unlocking function
S44A	Remote central locking
S53B	Remote real-time monitoring with GPS
S54A	Integrated hood ajar alarm switch
S57A	Pedestrian warning control system
S61A	Remote start - engine
S62B	Reversing lamp 2
S65A	Headlamp delay off
S67A	Anti theft deadlock
S68A	Rear 4 sensor
S68C	4 sensors at the front and 4 sensors at the rear
S70E	Blind spot monitoring system, type E
S72A	Automatic falling lock with speed
S73A	AEB system
S74A	Intelligent speed assist system
S75A	Emergency call
S78A	360 panoramic image, color, analog
S82F	Front impact sensor
S83C	Inductive wireless charging equipment
S891	Driving mode 1

Definition of Power Supply

According different power status, battery power is numbered as KL30, KLR, KL15, KL15 SW, KL50, KL58, KL31.

"KL30" means 12V battery power.

"KL15/KL15 SW" means battery power with START/STOP Switch in position ON/READY.

"KLR" means battery power with START/STOP Switch in position ACC.


"KL50" means battery power with START/STOP Switch in position START.

"KL58" means battery power with master light switch in position I and II.

"KL31" means earth ground.

Power Supply Symbol

The symbols of power supply in the circuit diagram are expressed as follows:




Connector Details

General

Connector means harness terminal connector.

Connector information includes name, description, colour, location view, face view and cavity information.

- **Connector Name:** The number is composed of the prefix of harness abbreviation and 3 serial number. For example, BY001 indicates the 001 connector of body harness.
- **Connector Description:** Describe the function of the connector, which is usually named after the components connected to the connector. For example, "Body Control Module-1" refers to the connector connected to interface 1 of the body control module. The name of inline connector depends on the harness name at both ends. For example, 'Inline-Driver Door Harness to Body Harness' refers to the connector on the body harness that connect with the facia harness.
- **Connector Colour:** Colour of connector plastic parts. If the colour of connector shell and inner core is inconsistent, the colour of connector inner core shall prevail.
- **Connector Location View:** Indicates the approximate position of the connector on the vehicle.
- **Connector Face View:** Show the shape, outline and end face structure of the connector, and mark the pin number, as shown in the figure below.



Face View Example Photograph

- **Connector Cavity Information:** The wire information (cross-sectional area, colour and option code) of each connector cavity terminal is listed in the form of table. If there is no wire terminal in the cavity, the cavity information will not be displayed in the table.

Fault Diagnosis

General

When diagnosing an electrical fault, follow the steps below:

1. Study the circuit diagram appropriate to the reported fault to ensure a good understanding of circuit operation.
2. Study the power distribution, fuse details diagrams and identify other circuits which share fuses and/or earth points. Check whether these circuits operate correctly.
3. Using the photographs contained in the connector section, locate a point on the circuit (approximately half way between supply and earth) which is easily accessible.
4. Check that the PIN out details of the connector are correct and that the correct signals exist at the correct terminals.
5. Continue to the next point on the circuit which is easiest to access and repeat the above.
6. Continue with this approach until a fault is found, rectify the fault and then verify that the circuit operates correctly.


WARNING: Never probe directly into the front face of a connector. This can damage the terminal and cause a failure. Always probe the back of a terminal, taking care not to damage the terminal or any seals.

WARNING: Never probe the wire insulation. On small diameter cables this can cut the conductors. It may also allow moisture into the cable, causing corrosion.

How to Use This Circuit

Component Symbol


In the below picture, there are normal electrical components referred in this Document.



Fuse Symbol


There are many types of fuses.

In the below picture, there are normal kinds of fuses and their instructions referred in this Document.



How to Use This Circuit


Controller/Device



Symbols of controller and device is as shown in the figure above.


If all pins connected is shown in this page, the border of controller/device will be full line, or there will be a lightning symbol in the border.

Shielded Wire



A shielded wire is shown as illustration.

Twisted Pair Wires



Twisted pair wires are shown as illustration.

How to Use This Circuit

Wire Attribute



0.35 means wire sectional area, the unit is square millimeter.

GP means wire color, the main color is green and second color is purple.

The coloured circuit diagrams show the actual wiring colours.

S40P is the option of this wire. You can refer option codes in option code list.


Wire option code can be combined by [AND], [OR], [NOT], the symbols are as follows.

[AND]: &, &&

[OR]: /, ||

[NOT]: !


Harness Connector on Device



The component connector is shown as an illustration. The information provided lists the connector number, wiring pin number and connector type.

This figure means the PIN1 & PIN2 of the female connector FA040 is connected with gateway.

Inline Connector




The in-line connector is shown as illustration.

EB070 & EM001 means the numbers of the in-line connectors.


The symbol of dark blue with pin is male connector, and the other is female.

The illustration means PIN11 and PIN 21 are connected with each other of EB070 and EM001.


CF01-Passenger Compartment Power Distribution(1)




CF02-Passenger Compartment Power Distribution(2)




CF03-Passenger Compartment Power Distribution(3)




EF01-Front Compartment Power Distribution(1)




EF02-Front Compartment Power Distribution(2)




EF04-Front Compartment Power Distribution(4)





EF05-Front Compartment Power Distribution(5)




G01-Ground Circuit(1)









G04-Ground Circuit(4)











S01-Body Control Module


KL30




S03-Combined Charging Unit




S04-Electric Vehicle Communication Controller




S06-High Voltage Distribution System




S08-Intelligent Electronic Control System(2)




S09-Intelligent Electronic Control System(3)




S10-Gateway & Electrical Battery Sensor



S13-Brake System(1)




S15-Brake System(3)




S16-Electric Power Steering


KL30




S17-Electronic Steering Column Lock




S19-Active Grille Shutter




S20-Air Conditioning System(1)




S21-Air Conditioning System(2)



S22-Air Conditioning System(3)




S23-Air Conditioning System(4)




S26-Driver Seat Adjust Switch

KL30




S28-Passive Entry Passive Start




S29-Door Locking System(1)

KL30




S31-Door Locking System(3)




S32-Driver Window Lift

KL30




S33-Passenger Window lift




S35-Rear Right Window Lift

KL30




S36-Exterior Mirrors


KL30




S39-Supplemental Restraint System(1)




S40-Supplemental Restraint System(2)




S41-Supplemental Restraint System(3)




S42-Front Wiper System




S43-Rear Wiper System




S44-Interior Lighting



S45-Illumination(1)




S46-Illumination(2)




S47-Main/Dipped Beam Headlamp

KL30




S48-Headlamp Levelling Switch

KL30




S50-Direction Indicator Lamp




S51-Towbar Harness Connection

KL30




S52-Brake Lamp & Reverse Lamp & Number Plate Lamp




S53-Parking Distance Control System


KL30




S54-Driving Assistance System




S55-Rear Driving Assistance System




S56-Around View System




S57-Driver Monitor System




S60-Pedestrian Alert System




S61-TBOX




KL30




S64-Entertainment System-Speaker(2)




S65-Entertainment System(1)




S66-Entertainment System(2)




S67-Entertainment System(3)




S68-Entertainment System(4)




S69-BUS System-Body High Speed Controller Area Network




S70-BUS System-Driver Assistance High Speed Controller Area Network




S71-BUS System-Chassis High Speed Controller Area Network




S73-BUS System-Powertrain High Speed (Extension) Controller Area Network




S74-BUS System-Diagnostic Line Connector




S75-BUS System-LIN(1)



S76-BUS System-LIN(2)




S77-BUS System-LIN(3)




Energy Storage System-51kWh&64kWh

Battery Management Module




Energy Storage System-51kWh&64kWh




Energy Storage System-51kWh&64kWh


Electrical Distribution Module-01



Current Measurement Unit-01




Electrical Distribution Module-01




Energy Storage System-51kWh&64kWh


Electrical Distribution Module-02



Current Measurement Unit-02




Electrical Distribution Module-02




Energy Storage System-51kWh&64kWh


Electrical Distribution Module-03




Current Measurement Unit-03




Electrical Distribution Module-03




Energy Storage System-51kWh&64kWh



ESS Internal Circuit-77kWh





ESS Internal Circuit-77kWh





ESS Internal Circuit-77kWh

Electrical Distribution Module-01




Current Measurement Unit-01




Electrical Distribution Module-01

ESS Internal Circuit-77kWh


Electrical Distribution Module-02



Current Measurement Unit-02




Electrical Distribution Module-02




ESS Internal Circuit-77kWh


Electrical Distribution Module-03



Current Measurement Unit-03



Electrical Distribution Module-03



ESS Internal Circuit-77kWh

